

ProBase[®] II Cradle

FOR SOLUTIONS LINEAR DRAINS

Installation Instructions

www.noblecompany.com

INSTALLING PROBASE II CRADLE

NOTE: Cradle to be installed before Solutions Drain is installed.

1. Using a directional trowel, apply modified thin-set mortar or Noble Bond EXT to the substrate.
2. Press cradle into modified thin-set (or Noble Bond EXT) on the substrate.
3. Apply small bead of NobleSealant 250 onto cradle flange.
4. Embed drain body into NobleSealant 250



Simple Solutions... Proven Performance



7300 Enterprise Drive, Spring Lake, MI 49456 · (800) 878-5788

Fax: (231) 799-8850 · www.noblecompany.com

® Registered Trademark of Noble Company © 2022 Noble Company



File # PB052022-05

05/22