

FreeStyle Linear Drain™ Tile Top Strainer Mortar Bed Adapter Kit

Installation Instructions

www.noblecompany.com


Step 14 of FreeStyle Linear Drain – Full Mortar Bed Adapter Kit Instructions

Use these screws to secure the brackets.



Step 21 of FreeStyle Linear Drain – Full Mortar Bed Adapter Kit Instructions and Step 3.1 of FreeStyle Linear Drain – Tile Top Strainer Instructions

These are the # 10-24 x 2-1/4" Flat Phillips Head Strainer Height Adjustment Screws for a Tile Top Strainer when used with a Full Mortar Bed Adapter Kit.



[Actual Size of Screw]



Step 3.2 of FreeStyle Linear Drain – Tile Top Strainer Instructions

Screw these two (2) stand-offs into the drain, one at each end of the drain base (see photos A and B below). The pins on the Tile Top Strainer will slip into the holes on the top of these stand-offs.



Installation of stand-off pins into end of Linear Drain base. Installation of Tile Top Strainer pins into stand-offs.

