

VIEW PRODUCT  
VIDEOS, DETAILS,  
AND DIAGRAMS ONLINE



# Surround Kit

## Waterproofing Kit for Tub or Shower Base Installations

Installation Instructions

[www.noblecompany.com](http://www.noblecompany.com)

### 1. GENERAL INFORMATION:

The Surround Kit contains a 3' x 33.3' roll of AquaSeal™, 5" x 16.5' AquaSeal Cap strip, 10.3 oz tube of NobleSealant 250, Thin-Line™ Pipe Collar, and a Thin-Line Mixing Valve Collar.

**NOTE:** A) Install in strict compliance with these instructions, all applicable ANSI standards, TCNA recommendations, and applicable building codes  
B) For any procedure not covered by these instructions, contact Noble Company.  
C) Refer to Surround Kit Product Description for test results and additional product data.

### 2. MATERIALS:

**2.1 PRODUCT:** The Surround Kit is designed for waterproofing and transitioning walls to shower bases and tubs with a nailing flange.

**2.2 CAP STRIP:** 5" x 16.5' banding for transitioning nailing flange to the wall. (waterproofing).

**2.3 BOND COAT:** The Surround Kit should be bonded with a modified thin-set mortar. Thin-set must conform to appropriate ANSI standards, TCNA handbook recommendations, and manufacturer's instructions.

**NOTE:** A) If using NobleBond EXT, refer to section 4.2.

B) Refer to bond coat manufacturer's instructions for cure time.

**2.4 NOBLESEALANT 250:** Used to seam sheets, seal penetrations (i.e., pipes and wires), and terminal edges.

**2.5 THIN-LINE MIXING VALVE AND PIPE COLLARS:** Install where pipes penetrate wall membrane.

**NOTE:** Additional Mixing Valve Collars and Pipe Collars can be purchased

**2.6 TOOLS:** Normal tile setting tools (i.e., 1/8" – 1/4" v-notch trowel), margin trowel, flat-edge trowel, hand roller, scissors or utility knife, and a commercial grade caulk gun for the application of NobleSealant 250.

### 3. PLANNING:

**3.1 CLEAN SURFACES:** Make sure surfaces are clean of all debris and bond breakers (i.e., dust, sealers, and solvents) before installing AquaSeal.

**3.2 MASKING:** Mask off tub deck and protect tub or shower base.

### 4. INSTALLATION:

**4.1 CAP STRIP:** Bond Cap Strip or membrane to backer board using modified thin-set. Make sure to terminate at the tub or shower deck using NobleSealant 250.

**4.2 AQUASEAL:** Bond AquaSeal membrane to walls using modified thinset or NobleBond EXT making sure to lap all seams a minimum of 2".

**NOTE:** If using NobleBond EXT, additional NobleSealant 250 will be needed for seaming.

**4.3 PENETRATIONS:** All penetrations must be sealed with a Thin-Line Pipe Collar or Mixing Valve Collar using modified thin-set or NobleSealant 250 to bond Thin-Line products to AquaSeal around penetrations.

### 5. TILE INSTALLATION:

**5.1 INSTALL TILE:** Set tile in accordance with TCNA Handbook and ANSI standards. Always follow bond coat manufacturer's instructions. Complete coverage of fabric by the bond coat is required.

**FOR ANY APPLICATIONS OR PROCEDURES NOT COVERED  
IN THESE INSTRUCTIONS, CONTACT NOBLE COMPANY.**



7300 Enterprise Drive, Spring Lake, MI 49456 · (800) 878-5788 · Fax: (231) 799-8850 · [www.noblecompany.com](http://www.noblecompany.com)  
© Registered Trademark of Noble Company™ Trademark of Noble Company © 2023 Noble Company

File #SK032023-22 | 03/23