

# ***AquaBlue™ as a Primer for Gypsum-Based Underlayment***



Technical Bulletin

[www.noblecompany.com](http://www.noblecompany.com)

***AquaBlue***, by Noble Company, when diluted 10%, can be used as a priming coat for gypsum-based underlayments. Refer to Section 5 of the current installation instructions for applying *AquaBlue* over a porous substrate. Additional coats of *AquaBlue* or Noble's sheet membranes can be applied/installed 30 minutes after diluted priming coat. Application suitability of *AquaBlue* as a primer should be verified with gypsum underlayment manufacturer.

Noble Company provides comprehensive, printed installation instructions for all of its products. However, the Noble Company is not responsible for the proper installation of the products it manufactures or distributes.

Contact Noble Company at (800) 578-5788 for additional information.



7300 Enterprise Drive · Spring Lake, MI 49456 · (800) 878-5788 · Fax: (231) 799-8850  
® Registered Trademark of Noble Company™ Trademark of Noble Company  
© 2021 Noble Company · [www.noblecompany.com](http://www.noblecompany.com)

File #TB032021-06 | 03/21

