



# Determining Depth Needed for NobleFlex® Drain Flashing

Technical Bulletin #016


[www.noblecompany.com](http://www.noblecompany.com)

## Description:

*To determine the depth of the NobleFlex Drain Flashing needed for a thin bed installation:*

1. Place clamping collar in the drain body in the “low profile” position.
2. Screw strainer into the clamping collar to the lowest position.
3. Measure the distance from the top of the drain body to the top of the strainer.

The depth of the NobleFlex Drain Flashing should be no less than the measured height (e.g. in sample below, 1-1/2” Flashing for a measurement of 1-5/16).



P.O. Box 350 · Grand Haven, MI 49417-0350 · 800-878-5788 · Fax: 231-799-8850  
© Registered Trademark of Noble Company™ Trademark of Noble Company, Grand Haven, MI.  
© 2016 Noble Company · [www.noblecompany.com](http://www.noblecompany.com)

File #TB092016-07 | 09/16 | Supersedes TB122015-03

