

# Noble Benches

## Installation Instructions

www.noblecompany.com

### PRODUCT & MATERIALS

1. **NOBLE BENCHES:** Noble Benches are made from high-density expanded polystyrene with an acrylic polymer finish and are waterproof and ready to tile. They are lightweight, durable, and not a food source for fungus and mold.
2. **OTHER TOOLS & MATERIALS NEEDED:** Mortar Mix (for leveling), 1/2" x 1/2" Square-Notch trowel, Modified Thin-Set, and NobleSealant 250 or 100% Silicone Sealant.

### PREPARATORY WORK

1. **WATERPROOFING:** Shower should be waterproofed in accordance with Tile Council of North America (TCNA) guidelines and all applicable codes prior to the installation of the bench.
2. **WALLS:** Ensure that the walls where the bench is to be installed are square and plumb.
3. **FLOOR:** In order for the bench to fit the walls, the floor under the bench must be square to the walls (i.e. leveled/free of slope). Use a mortar mix beneath the bench for leveling.
4. **VERIFY:** Re-check the fit of the bench with the walls and floor and repeat until the fit is square and level.







### INSTALLING BENCH


1. **MODIFIED THIN-SET:** Apply a medium bed, modified thin-set to the walls behind the bench and on the floor under the bench. Use a 1/2" x 1/2" Square-Notch trowel.
2. **KEYING:** Key in a thin layer of modified thin-set on the sides and bottom of the bench to help ensure a tight bond.
3. **INSTALL BENCH:** Slide the bench into the thin-set, flattening the ridges.
4. **VERIFY:** Ensure that there is complete coverage of the thin-set.
5. **SEAL JOINTS:** Once the bench is installed, use NobleSealant 250 or 100% Silicone Sealant to seal all joints where the bench meets the walls.
6. **TILE:** Install tile or stone according to TCNA guidelines.

### ATTACHING BENCHES TOGETHER


1. **DRY-FIT:** Dry fit one bench to the other to ensure proper fit.
2. **MODIFIED THIN-SET:** Apply a medium bed, modified thin-set to the walls behind the bench and on the floor under the bench. Also apply thin-set to the side of the bench that is already installed. Use a 1/2" x 1/2" Square-Notch trowel.
3. **INSTALL BENCH:** Slide the bench into the thin-set, flattening the ridges.
4. **VERIFY:** Ensure that there is complete coverage of the thin-set.
5. **SEAL JOINTS:** Once the bench is installed, use NobleSealant 250 or 100% Silicone Sealant to seal all joints where the bench meets the walls and where the benches meet.
6. **TILE:** Install tile or stone according to TCNA guidelines.

**NOTE:** For any situation not specifically covered above, contact Noble Company's Technical Department at (800) 878-5788 before proceeding. Always follow TCNA guidelines.







**CURVED BENCH**  
Item #406  
15 1/2" R x 20" H




**SMALL TRIANGLE BENCH**  
Item #400  
15 1/2" D x 22" W x 20" H




**LARGE TRIANGLE BENCH**  
Item #402  
23" D x 32 1/2" W x 20" H




**SQUARE BENCH**  
Item #404  
11 1/2" D x 11 1/2" W x 20" H



**SMALL RECTANGLE BENCH - 36**  
Item #412  
11 1/2" D x 36" W x 20" H




**LARGE RECTANGLE BENCH - 36**  
Item #411  
15 1/2" D x 36" W x 20" H




**SHELF BENCH\***  
Item #414  
22 7/8" D x 32 5/16" W x 4" H

\*Follow "SHELF BENCH  
INSTALLATION INSTRUCTIONS"



**SMALL RECTANGLE BENCH - 48**  
Item #409  
11 1/2" D x 48" W x 20" H



**LARGE RECTANGLE BENCH - 48**  
Item #4004  
15 1/2" D x 47 3/4" W x 20" H