

# **NOBURST®**

## **HYDRONIC SYSTEM CLEANER**

**NOBURST®** Hydronic System Cleaner safely and efficiently removes scale, rust, and other foreign materials from hydronic systems. It improves heating efficiency of your Hydronic/Radiant system.

**NOBURST** Hydronic System Cleaner and **NOBURST** Hydronic Antifreeze should be used by contractors familiar with the servicing of hydronic heating and cooling systems.

### **DIRECTIONS:**

1. Determine the system capacity. Include all pipe and the boiler.
2. Fill the system with fresh water.
3. Use one pint of **NOBURST** System Pre-Cleaner for each 50 gallons, or part of 50 gallons of system capacity. Dissolve each container of Pre-Cleaner in one gallon of warm to hot distilled or deionized water.
4. Draw off water from system to make room for the cleaning solution.
5. Circulate solution through the entire system and rapidly bring the fluid temperature to system maximum (at least 180°F).
6. Run the system at high operating temperature for 8-24 hours. Drain solution while still hot. Add fresh water to system and circulate to rinse. Purge solution.
7. System is now ready for **NOBURST®** Hydronic Heating and Heat Transfer Anti freeze.



### **Noble Company**

7300 Enterprise Drive/ Spring Lake, Michigan 49456  
Phone: 800-878-5788/Fax: 231-799-8850  
[www.noblecompany.com](http://www.noblecompany.com)